Brief User Manual FCUxxxx

Status display
Heating 1
Evaporator 2
Drying program active 3
Infrared 4

Mode keys
Sauna 5

Sauna with humidity 6

Infrared 7

Power switch
Main switch „ON" 8
Main switch „OFF" 9
Cleaning light „ON" 20

Only glas-keyboard
ON/OFF-key 8/9 G

1
2
3
4

5

6

7

8
9/19
20

FCUxxxx
+
FCUxxxx-Design-Glas

8
9

..-DESIGN

8/9 G

..-DESIGN-GLAS

10
11
12
13

14

15

16

17
18

19
20

Menu display
10 Temperature
11 Humidity
12 Heating duration
13 Timer

14 Display

Keys
15 Light

16 Fan

17 Menu
18 Navigation keys
Power switch
19 Cleaning light „OFF"
20 Cleaning light „ON"

Manuel start:

1. **Switch on:**
   Push main switch (8) and possibly key (8G) once
2. **If necessary change mode:**
   Push key Sauna (5), Sauna with humidity (6) or Infrared (7) once. The light in the key flashes
3. **Start mode:**
   Push key Sauna (5), Sauna with humidity (6) or Infrared (7) once. The light in the key flashes

Automatic Timer-start:

1. Switch on (see point 1 on the left)
2. Push key ▼ or ▲ until symbol Timer (13) lights
3. Select with key ↵
4. Enter desired start time with keys ◄ ► ▼▲
5. Confirm with key ↵
6. Push key Sauna (5), Sauna with humidity (6) or Infrared (7) once
7. The symbol Timer (13) and the light in key (5, 6 or 7) flash

Change the values set

1. Push key ▼ or ▲ until one of the symbols Temperature (10), Humidity (11), Heating time (12) or Timer (13) lights
2. Select with key ↵
3. Enter desired value with keys ◄ ► ▼▲
4. Confirm with key ↵